




GES-80 Series Conveyors Operating Manual



Dorner GmbH
Karl-Heinz-Beckurts-Str. 7
D-52428 Jülich
Germany

Phone: +49 2461 93767 0
Fax: +49 2461 93767 30

E-Mail: info.europe@dorner.com
Web: www.dorner.com

**Please read
carefully
before use of
machine**

**Also applies to:
GES-80-M
GES-80-K
GES-80-Z
GES-80-S**

Table of contents:

- 1 Introduction 4
- 2 Safety during handling of our belt conveyors..... 4
 - 2.1 Safety equipment on our belt conveyors 4
 - 2.2 General advice for the correct handling of belt conveyors 4
 - 2.3 Duties of the operator 5
 - 2.4 Safety trade marks..... 5
- 3 Dimensions and technical data 6
 - 3.1 Basic dimensions 6
 - 3.1.1 Dimensions of the GES-80-M, GKES-80, GES-80-K, GES-80-Z and GES-80-S:..... 7
 - 3.2 Belts 8
 - 3.3 Motors 9
 - 3.3.1 Geared motor, type SN3F: 9
 - 3.3.2 Geared motor, type SN9F: 10
 - 3.3.3 Geared motor, type SN8F: 11
 - 3.4 Electrical equipment 12
 - 3.4.1 Frequency converter..... 12
 - 3.4.2 Motor overload switch..... 13
 - 3.4.3 Emergency-stop-switch 14
- 4 Adjustments 15
 - 4.1 Drives..... 15
 - 4.1.1 Drive underneath the belt 15
 - 4.1.2 Side mounted drive..... 15
 - 4.2 Belt alignment 17
 - 4.2.1 Drive roller or deflecting roller: 18
 - 4.2.2 Belt alignment at lower kink of GES-80-K/KW: 18
 - 4.2.3 Belt alignment at upper kink of GES-80-Z/ZW and GES-80-S: 19
 - 4.3 Supports..... 21
 - 4.3.1 Protection against tip-over of flat belt conveyors 21
 - 4.3.2 Two-legged aluminium support 22
 - 4.3.3 Two-legged aluminium support, short version 22
 - 4.3.4 Two-legged steel support 23
 - 4.3.5 Two-legged steel support, short version 23
 - 4.3.6 Short steel support held from side..... 24
 - 4.3.7 Two-legged stainless steel support 24
 - 4.3.8 Single-legged steel support with aluminium base plate 25
 - 4.3.9 Steel H-shaped single-legged support 25
 - 4.3.10 Steel H-shaped single-legged support with castors..... 26
 - 4.3.11 Stainless steel H-shaped single-legged support 26
 - 4.3.12 Stainless steel H-shaped single-legged support with castors..... 26
 - 4.4 Kinks 27
- 5 Spare parts..... 28

Table of figures:

Figure 3-1:	Basic dimensions GES-80.....	6
Figure 3-2:	Basic dimensions GKES-80	6
Figure 3-3:	Basic dimensions GES-80-KW.....	7
Figure 3-4:	Basic dimensions GES-80-ZW	7
Figure 3-5:	Table on belt types	8
Figure 3-6:	Frequency converter.....	12
Figure 3-7:	Connection of frequency converter to motor	12
Figure 3-8:	Motor overload switch.....	13
Figure 3-9:	Connection of overload switch to motor	13
Figure 3-10:	Emergency-stop-switch	14
Figure 3-12:	Connection of emergency-stop-switch to 380V 50Hz	14
Figure 3-11:	Connection of emergency-stop-switch to 230V 50Hz	14
Figure 4-1:	Dismounting side motor.....	15
Figure 4-2:	Adjustment of clutch play	15
Figure 4-3:	Rotated installation positions of the motor	16
Figure 4-4:	Belt reaction to different bracket positions	17
Figure 4-5:	Tracking of belt using supporting rollers	17
Figure 4-6:	Belt alignment at drive roller or deflecting roller	18
Figure 4-7:	Axial distances on kinked belt conveyor	18
Figure 4-8:	Belt alignment in the lower kink.....	19
Figure 4-9:	Axial distances on Z-shaped belt conveyor.....	19
Figure 4-10:	Belt alignment in upper kink.....	20
Figure 4-11:	Maximum weight at end of conveyor with supports on wheels	21
Figure 4-12:	Two-legged aluminium support, height adjustment.....	22
Figure 4-13:	Two-legged aluminium support, inclination adjustment.....	22
Figure 4-14:	Two-legged steel support, height adjustment.....	23
Figure 4-15:	Two-legged steel support, inclination adjustment	23
Figure 4-16:	Short steel support held from side, height adjustment	24
Figure 4-17:	Single-legged steel support with aluminium base plate, height adjustment.....	25
Figure 4-18:	Single-legged steel support with aluminium base plate, inclination adjustment	25
Figure 4-19:	Steel H-shaped single-legged support, brake	26
Figure 4-20:	Adjustable kink, angle range.....	27
Figure 4-21:	Adjustment of kink angle.....	27
Figure 4-22:	Adjustment of kink angle in upper kink	28

1 Introduction

Our belt conveyors are provided for inside use only; they are not suitable for damp and wet locations or areas exposed to danger of explosion. However special versions, which are suitable for such areas, can be supplied after consultation and confirmation.

Maintenance of the belt conveyors is limited to an occasional check of the running of the belt. To adjust the belt we recommend strongly to observe the advice given in this operating manual.

2 Safety during handling of our belt conveyors

All our standard belt conveyors were designed with special emphasis on safety. Specially during operation of the belt conveyors, unnecessary risks have to be avoided. Thus the design of many components has been carried out in such a way that the risk to injury of the operating personnel is minimised.

2.1 Safety equipment on our belt conveyors

One of the most frequent type of accidents when working on or with conveyors is injury sustained to parts of the body which are caught between the circulating belt and the rotating rollers. To make these accidents impossible or to minimise this risk to the widest extent, all Dorner belt conveyors are equipped with a gap protection wherever the belt runs over a roller. This gap protection is designed in such a way that during adjustment work it is automatically positioned in correct relation to the roller.

To avoid damages to electrical equipment and to minimise the risk of electrical shock, all parts of our belt conveyors are connected to earth.

For all our belt conveyors we provide a safety switch which cuts-off the current to the unit automatically in the case of overload or overheating. In addition to that each conveyor has an emergency-stop-switch to switch-off the belt conveyor quickly in any case of emergency. See also section 3.4.

If a belt conveyor is delivered without safety switch or emergency stop switch, the operator must ensure a correct set-up of the machine and provide an opportunity to stop the belt in case of emergency.

2.2 General advice for the correct handling of belt conveyors

Any work or installation on the mechanical part of the conveyors may only be carried out by a mechanic or personnel with equivalent education or indoctrination. Any work or installation on the electrical part of the conveyors may only be carried out by an electrician or personnel with equivalent education or indoctrination.

The operators and all personnel working on or with a conveyor should wear suitable protective clothing. That includes safety shoes for protection against falling objects as well as tight fitting clothes and hair nets for people with long hair to minimise the risk of getting caught in the belt.

A functional test of the security-stop-switch should be performed daily. That includes a test of the protection against uncontrolled restart after a voltage drop. The conveyor may not start by it self after a voltage drop. It may only start after the actuation of a button.

The working height should be adjusted to an ergonomic level, if that is possible and wanted.

Touching the belt while it is running is prohibited. People may not be transported on the belt.

In case of an emergency the belt of the conveyor can be moved backwards by pulling on it.

2.3 Duties of the operator

The operator of a conveyor has to make sure that all requirements for a safe operation of the device are met. Therefore the following has to be taken into account:

- There has to be sufficient lighting at each persons workplace.
- The conveyors can only be used in inside areas.
- The maximum weights must not be exceeded. With this the danger of tipping over a conveyor on supports with wheels has to be taken into account.
- Accessory added later must not endanger the operators.

2.4 Safety trade marks

Some of our standard belt conveyors can be equipped with special safety trade marks. These will be attached to the machine on request.

Based on an individual application of the belt conveyor, an individual adaptation may be required. This can be provided by us as the manufacturer or by the client himself. In both cases, a cancellation of the validity of the safety trade mark may be the result.

3 Dimensions and technical data

3.1 Basic dimensions

The most important dimensions of the belt conveyor GES-80, GES-80-M, GKES-80, GES-80-K/KW and GES-80-Z/ZW are shown in the following figures:




Figure 3-1: Basic dimensions GES-80




Figure 3-2: Basic dimensions GKES-80




Figure 3-3: Basic dimensions GES-80-KW




Figure 3-4: Basic dimensions GES-80-ZW

3.1.1 Dimensions of the GES-80-M, GKES-80, GES-80-K, GES-80-Z and GES-80-S:

- The dimensions of the GES-80-M are equal to those of the GES-80.
- The dimensions of the GKES-80 are equal to those of the GES-80.
- The dimensions of the GES-80-K are equal to those of the GES-80-KW.
- The dimensions of the GES-80-Z are equal to those of the GES-80-ZW.
- The dimensions of the GES-80-S are equal to those of the GES-80-ZW.

3.2 Belts

The following table contains the technical data of our most frequently used belt types. All of these can be equipped with cross slats and corrugated edges.


	Belt type					
	G1	G3 PVC	G3 PU blue	G3 PU white	G4 Mini	G4 Super
Load at elongation of 1% in N per mm width	8	8	10	8	10	8
Fabric type	Polyester	Polyester	Polyester, laterally stable	Polyester	Polyester	Polyester
No. of layers	2	2	2	2	2	2
Colour	grey	blue/green	blue	white	blue/green	blue/green
Material on carrying side	PVC	PVC	PU	PU	PVC	PVC
Surface on carrying side	fabric	smooth coated, slightly sticky	smooth matt	smooth matt	structured	structured
Thickness	1,5 mm	2,1 mm	2,3 mm	1,4 mm	2,7 mm	5,1 mm
Material on running side	fabric	fabric	fabric	fabric	fabric	fabric
Antistatic	no	yes	no	yes	no	no
Resistant against oil and grease	yes	partly	yes	yes	yes	no
FDA-approved	no	no	yes	yes	no	no
Temperature range	-10°C bis +80°C	-10°C to +80°C	-25°C to +90°C	-25°C to +90°C	-10°C to +110°C	-10°C to +80°C
Minimum diameter of roller	30	30	30	30	30	60

Figure 3-5: Table on belt types

3.3 Motors

As a standard, our belt conveyors are equipped with three-phase AC motors and worm gears, protection class IP65. You can find dimensions and technical data of various standard motors below. Also special motors are available on request. Adjustment and maintenance of drive chains and clutches are described in section 4.


3.3.1 Geared motor, type SN3F:



Mounting dimensions							Outline dimensions										Shaft dimensions					
c ₁	ød ₁	ød ₂	ød ₃	ød ₄	j	øS ₁	g	g ₁	k	k ₁	o	o ₁	q	q ₁	y	z	ød	l	l ₁	l ₂	t	u
10	120	100	80	52	3	M6	125	108	235	187	41,5	33	99	35	30	74	14	30,0	20	5	16,0	5

Gearbox data						
Motor data	180 Watt, 1400 rpm, weight 6,1Kg, 0,7Amps with 380V, IP65					
Gearbox ratio	7 : 1	10 : 1	15 : 1	20 : 1	30 : 1	56 : 1
Gearbox speed	200 rpm	140 rpm	93 rpm	70 rpm	47 rpm	25 rpm
Effective torque	6,7 Nm	10 Nm	12 Nm	12 Nm	14 Nm	17 Nm
max. permissible torque	12 Nm	12 Nm	13 Nm	13 Nm	13 Nm	10 Nm


3.3.2 Geared motor, type SN9F:



Mounting dimensions							Outline dimensions							Shaft dimensions									
c ₁	ød ₁	ød ₂	ød ₃	ød ₄	j	øS ₁	g	g ₁	k	k ₁	o	o ₁	q	q ₁	y	z	ød	i	l	l ₁	l ₂	t	u
8	120	100	80	65	3	7	140	114	327	207	60	40	102	40	25	121	16	1	35	25	5	18	5

Gearbox data						
Motor data	370 Watt, 1400 rpm, weight 9,2Kg, 1,2Amps with 380V, IP65					
Gearbox ratio	7 : 1	10 : 1	15 : 1	20 : 1	30 : 1	50 : 1
Gearbox speed	207 rpm	140 rpm	93 rpm	70 rpm	47 rpm	28 rpm
Effective torque	14 Nm	20 Nm	27 Nm	29 Nm	36 Nm	48 Nm
max. permissible torque	30 Nm	30 Nm	28 Nm	29 Nm	30 Nm	27 Nm

3.3.3 Geared motor, type SN8F:



Mounting dimensions							Outline dimensions										Shaft dimensions						
c ₁	ød ₁	ød ₂	ød ₃	ød ₄	j	øS ₁	g	g ₁	k	k ₁	o	o ₁	q	q ₁	y	z	ød	i	l	l ₁	l ₂	t	u
10	120	100	80	80	3	7	140	114	334	207	67	53	124	46	25	141	20	1	50	30	10	22,5	6

Gearbox data						
Motor data	550 Watt, 1400 rpm, weight 10,7Kg, 1,6Amps with 380V, IP65					
Gearbox ratio	7 : 1	10 : 1	15 : 1	21 : 1	30 : 1	50 : 1
Gearbox speed	210 rpm	145 rpm	93 rpm	67 rpm	47 rpm	28 rpm
Effective torque	21 Nm	28 Nm	41 Nm	50 Nm	56 Nm	60 Nm
max. permissible torque	56 Nm	57 Nm	60 Nm	57 Nm	59 Nm	51 Nm

3.4 Electrical equipment

All our electrical equipment must only be exposed to liquids or dust within the regulations applicable to their protection type classification. Any contact to liquids or dust surpassing these limitations must be avoided.

3.4.1 Frequency converter

All of our belt conveyors – provided a regulated belt speed is required – can be equipped with a frequency converter which controls a robust three-phase AC motor.

The converter GB-FU 180 is used with all motors up to 180 W. Motors with a power between 180 and 370 W are equipped with the converter GB-FU 370. Motors of higher performance than 370 W are fitted with a specially adapted frequency converter.



Figure 3-6: Frequency converter




Figure 3-7: Connection of frequency converter to motor

All frequency converters are digital units which can be individually programmed. Each frequency converter also provides a motor overload protection. Thus a destruction of the motor by a jammed belt conveyor through mechanical faults is virtually impossible. In this case, the frequency converter cuts-off the current supply. Frequency converters are connected to 230V 50Hz AC. These units have a separate operating manual which will be provided with each delivery.

Additionally the frequency converter incorporates a stop switch in form of a red push button for fast cut off in case of an emergency. After the drop or loss of current the conveyor also doesn't restart by itself. A dedicated start button has to be pushed.

3.4.2 Motor overload switch

All of our belt conveyors – provided a constant belt speed is required – can be equipped with a motor overload switch which controls a robust three-phase AC motor.



Figure 3-8: Motor overload switch




Figure 3-9: Connection of overload switch to motor

The motor overload switch protects the motor from overload. Thus a destruction of the motor by a jammed conveyor belt through mechanical faults is virtually impossible. In this case, the motor overload switch cuts-off the current supply. In addition, the motor overload switch is equipped with an emergency-stop-switch designed as a snap-switch providing a quick shut-down of the belt conveyor. The motor overload switch is connected to 380V 50Hz three-phase current.

3.4.3 Emergency-stop-switch

In addition, all belt conveyors can be equipped with one or more mushroom shaped emergency-stop-switches.

The emergency-stop-switch is connected in series between power source and conveyor belt, so that actuating one of the switches shuts down the complete belt conveyor.




Figure 3-10: Emergency-stop-switch




Figure 3-12: Connection of emergency-stop-switch to 230V 50Hz




Figure 3-11: Connection of emergency-stop-switch to 380V 50Hz

4 Adjustments

Whenever adjustments are carried out, it has to be made sure that all covers or holders that had to be removed are reinstalled after the service and before the conveyors are used again.

4.1 Drives

4.1.1 Drive underneath the belt

None of our stainless steel conveyors is designed for a position of the motor hanging underneath the belt. Such a position cannot be recommended due to the expected amount of contamination.

4.1.2 Side mounted drive

If the drive motor is installed at the side of the conveyor belt, a correct adjustment of the clutch must be ensured.

As shown in the opposite figure, the motor (A) must be removed by undoing the fixing screws (B) to be able to adjust the clutch.




Figure 4-1: Dismounting side motor

If the clutch housing (E) is positioned between motor (A) and flange (F), then the distance between the clutch wheels (C) of the motor and the drive roller (D) must be approximately 15 mm, see the opposite figure. After adjustment of distance, the clutch sleeve (not shown in the figure) must be put on again on the clutch wheel (C) fitted to the drive roller (D). The fixing screws (B) must be retightened.




Figure 4-2: Adjustment of clutch play

If the motor is installed at the side of the conveyor belt, it can be mounted at 90° angular intervals around the flange, see the opposite figure.




Figure 4-3: Rotated installation positions of the motor

4.2 Belt alignment

The belt reacts to a repositioning of the brackets holding the roller as it is shown in the opposite figure.




Figure 4-4: Belt reaction to different bracket positions

With longer belt conveyors, supporting rollers are used on the underside of the conveyor to hold the belt up on its way back. These rollers can also be used for tracking of the belt. The following figure shows the reaction of the belt tracking when the holding plates of the supporting rollers are shifted.




Figure 4-5: Tracking of belt using supporting rollers

Attention:

In the case of kinked belt conveyors, always adjust the course of the belt at the kink first, then follow with deflecting and drive rollers.

4.2.1 Drive roller or deflecting roller:

To align the belt track on the drive roller or the deflecting roller, loosen slightly the fixing screws (A) of the head piece (B), see the opposite figure. The head unit (B) can then be moved in relation to the frame (E) by turning the adjustment screw (F). After adjustment, the fixing screws (A) must be firmly retightened.




Figure 4-6: Belt alignment at drive roller or deflecting roller

4.2.2 Belt alignment at lower kink of GES-80-K/KW:

Attention:

In the case of kink conveyor belts, always adjust the track of the belt at the kink first, then follow with deflector and drive rollers.

Before the adjustment of the belt tracking, the axial distances of all frame segments of the belt conveyors left side must be identical with the distances on the right side. An example is shown in the opposite figure. If the distance between head unit (A) of the deflection roller and shaft centre of the kink roller (B) on the left side of the conveyor belt is 500mm, then the distance on the right side must also be 500mm.




Figure 4-7: Axial distances on kinked belt conveyor

To align the belt in the area of the kink, the fixing screws (A) of the kink fittings (B) in the elevating part A2 must be loosened, see the opposite figure. Then the position of the kink roller (E) can be changed by turning the adjustment screws (F). At first the belt must run centrally across the kink roller (E), then you can continue to align the belt on the drive or deflection roller. Retighten the fixing screws (A) firmly after adjustment.




Figure 4-8: Belt alignment in the lower kink

4.2.3 Belt alignment at upper kink of GES-80-Z/ZW and GES-80-S:

For the adjustment of the upper kink of Z-shaped conveyors, the same rules apply as for the adjustment of the lower kink.

Before the adjustment of the belt tracking in the upper kink, the axial distances of all frame segments of the belt conveyors left side must be identical with the distances on the right side. An example is shown in the opposite figure. If the distance between kink roller (A) of the lower kink and kink roller (B) of the upper kink on the left side of the conveyor belt is 1000mm, then the distance on the right side must also be 1000mm.




Figure 4-9: Axial distances on Z-shaped belt conveyor

To align the belt in the area of the upper kink, the fixing screws (A) of the kink fittings (B) in the elevating part A2 must be loosened, see the opposite figure. Then the position of the kink roller (E) can be changed by turning the adjustment screws (F). At first the belt must run centrally across the kink roller (E) in the upper kink and, as described in the previous section, across the kink roller in the lower kink, then you can continue to align the belt on the drive or deflection roller. Retighten the fixing screws (A) firmly after adjustment.




Figure 4-10: Belt alignment in upper kink

4.3 Supports

4.3.1 Protection against tip-over of flat belt conveyors

Conveyors that are equipped with supports designed for a bolted connection to the ground should always be secured by such a joint.

Some of our support models come with security casters with brakes. With these the conveyor can easily be used at different locations. But these supports are less stable than those without wheels. Therefore the transport of the conveyor to a new location using a ramp or going up an inclination has to be additionally secured, because the conveyor might tip over.

While the conveyor is in use the supports should always be oriented as much towards the ends of the conveyor as possible. For a distance of 400mm between the end of the conveyor and the centre of the support (distance a) the following diagram shows the maximum weight admitted on the conveyor end for a known width and length of the conveyor.

Maximum weight at end of belt for GES-80 with supports on wheels




Figure 4-11: Maximum weight at end of conveyor with supports on wheels

4.3.2 Two-legged aluminium support

The aluminium double upright is continuously adjustable in height. At first the fixing screws (A) of the cross bar (B) must be loosened, see the opposite figure. Then the upright insert (C) can be pulled out of the tube (D). The standard adjustment range is 200mm. After adjustment, retighten firmly the two fixing screws (A).




Figure 4-12: Two-legged aluminium support, height adjustment

The aluminium double upright can also be continuously adjusted in its inclination. At first the fixing screws (A) must be loosened on the upright plate (B), like in the opposite figure. Then the head of the upright can be pivoted in the guidance (C) of the plates (B) from $+30^\circ$ up to -30° . In vertical position, the head of the upright snaps into the lock-in position (D) and is consequently secured against unintended pivoting. The aluminium double upright is also available with plates as a pivoting version ranging from horizontal up to vertical position.




Figure 4-13: Two-legged aluminium support, inclination adjustment

4.3.3 Two-legged aluminium support, short version

A shortened variant of the aluminium double upright is equipped with fixed castors. It is also height-adjustable as described in section 4.3.2, however, the adjustment range is only 50 mm and is intended to level out ground irregularities. The adjustment of inclination is the same as described in section 4.3.2.

4.3.4 Two-legged steel support

The steel double upright can be continuously adjusted in height. At first the fixing screws (A) of the cross bar (B) must be loosened, as shown in the opposite figure. Then the insert (C) can be pulled out of the upright tube (D). An adjustment range of 200mm is available as a standard. After adjustment, the two fixing screws (A) must be firmly retightened.




Figure 4-14: Two-legged steel support, height adjustment

The steel double upright can also be continuously adjusted in its inclination. At first the fixing screws (A) must be loosened on the upright plate (B), like in the opposite figure. Then the head of the upright can be pivoted in the guides (C) of the plates (B) from +30° up to -30°. In vertical position, the head of the upright snaps into the lock-in position (D) and is consequently secured against unintended pivoting. The steel double upright is also available with plates as a pivoting version ranging from horizontal up to vertical position.




Figure 4-15: Two-legged steel support, inclination adjustment

4.3.5 Two-legged steel support, short version

A shortened variant of the steel double upright is equipped with fixed castors. It is also height-adjustable as described in section 4.3.4, however, the adjustment range is only 50 mm and is intended to level out ground irregularities. The adjustment of inclination is the same as described in section 4.3.4.

4.3.6 Short steel support held from side

To adjust the height of a short steel support held from the side, first loosen the fixing screws (A) on the side plate (B), like in the opposite figure. Then the short support (C) can be adjusted within the guide (B). After adjustment, retighten the two fixing screws (A) firmly.




Figure 4-16: Short steel support held from side, height adjustment

4.3.7 Two-legged stainless steel support

The two-legged stainless steel support provides the same adjustment features as the two-legged steel support. It also exists in the same variants, i.e. the short version with fixed casters and the short version held from the side.

4.3.8 Single-legged steel support with aluminium base plate

The single-legged steel support with aluminium base plate can be continuously adjusted in height. First loosen the fixing screw (A) on the adjustment ring (B), see the opposite figure. The forked pipe (C) can then be pulled out of the standpipe (D). The adjustment range is 200mm. After adjustment, retighten the fixing screw (A) firmly.




Figure 4-17: Single-legged steel support with aluminium base plate, height adjustment

The single upright made of steel can also be continuously adjusted in its inclination. At first the fixing screws (A) must be loosened on the upright plate (B), like in the opposite figure. Then the head of the upright can be pivoted in the guides (C) of the plates (B) from horizontal to vertical position.




Figure 4-18: Single-legged steel support with aluminium base plate, inclination adjustment

4.3.9 Steel H-shaped single-legged support

The steel H-shaped single-legged support provides the same adjustment features as the steel single upright with aluminium base plate.

4.3.10 Steel H-shaped single-legged support with castors

The steel H-shaped single-legged support with castors provides the same adjustment features as the H-single upright made of steel. In addition, it is equipped with Total-Stop-Safety castors as shown in the opposite figure. When the brake is actuated, the upright is secured against unintentional movement.




Figure 4-19: Steel H-shaped single-legged support, brake

4.3.11 Stainless steel H-shaped single-legged support

The stainless steel H-shaped single-legged support provides the same adjustment features as its steel version described under 4.3.9.

4.3.12 Stainless steel H-shaped single-legged support with castors

The stainless steel H-shaped single-legged support with castors provides the same adjustment features as its steel version described under 4.3.10.

4.4 Kinks

The kink angle of all our conveyor belts can be adjusted between 40° and 60° from horizontal position. The adjustment of angles lower than 40° is not recommended, because this would have negative effects on the belt track. Before making any angle adjustment on one of our kinked conveyor belts, the belt must be slackened by loosening the deflection roller as described in section 4.2. After each change, the belt must be realigned as described in section 4.2.




Figure 4-20: Adjustable kink, angle range

To adjust the angle of the kink in the GES-80-KW, or of the lower kink in the GES-80-ZW, the fixing screw (A) on the kink fitting (B) must be loosened, see the opposite figure. The angle of the kink can then be changed. After adjustment of the kink angle, the fixing screw (A) must be firmly retightened.




Figure 4-21: Adjustment of kink angle

To adjust the angle of the upper kink in the GES-50-ZW, the fixing screw (A) on the kink fitting (B) must be loosened, see the opposite figure.

The angle of the kink can then be changed. After adjustment of the kink angle, the fixing screw (A) must be firmly retightened.





Figure 4-22: Adjustment of kink angle in upper kink

5 Spare parts

All components of the belt conveyor model GES-80, GES-80-M, GKES-80, GES-80-K/KW, GES-80-S and GES-80-Z/ZW are shown in the following exploded views. Any part on your conveyor, that is not shown in these views, is a specially adapted part. We keep a full record of all special parts in our production files. Please contact us directly if you need any help on one of these parts.




Allgemein- toleranz DIN 7168-m		Surface		Scale	1:1	Position	-	Quantity	-
Date	Name	Date	Name	GES-80					
08.12.2009	Hoeps	28.11.2005	Hoeps	Z-Nr.: 1016 A					
Checked 28.11.2005 Hoeps		Standard		Page					
Geppert-Band GmbH Tel: 0229 / 84 91 Fax: 0228 / 84 958		Büro		Pg					
State		Changes		Date		Name		File name	

1 2 3 4 5 6 7 8


A B C D E F

F E D C B A



Allgemein- toleranzen DIN 7168-m			Surface			Scale	1:1	Position	-	Quantity	-
Date						Name					
Drawn 28.11.2005						Meessen					
Checked 28.11.2005						Hoeps					
Standard											
Geppert-Brand GmbH Tel: 05259 / 844 99 Fax: 05258 / 84558											
Z-Nr.: 1016 B										Page	
										Pg	
28.11.2005											

State Changes Date Name Filename




- A gear drive _____ 741
- 714 _____ 702
- clutch wheel _____ 718
- clutch sleeve _____ 720
- clutch wheel _____ 718
- 743 _____ 718
- belt _____ 702
- 743 _____ 399
- bearing-SS-2204, 2RS _____ 702
- 742 _____ 742
- bearing-SS-2204, 2RS _____ 743
- 702 _____ 702
- 399 _____ 399
- 717 _____ 723
- 721 _____ 722
- 702 _____ 724
- bearing-SS-2204, 2RS _____ 719
- 742 _____ 719
- 743 _____ 719

Algemein- toleranz DIN 7168-m	Surface	Scale	1:1	Position	-	Quantity	-
Drawn 28.11.2005	Meessen	GES-80-M					
Checked 28.11.2005	Hoeps						
Standard							

Date	Name

State	Changes	Date	Name	Filename	Revision	Z-Nr.	1016 C	Page	-	Pg	28.11.2005

Gepfert-Brand GmbH
 Tel: 02208 / 844 99
 Fax: 02208 / 84398



Drawn	Date	Name	Surface	Scale	Position	Quantity
28.11.2005			1:1	-	-	-
Checked						
28.11.2005						
Standard						
Allgemein-toleranzen DIN 7168-m						

GES-80-M
with easy cleaning coupling

Z-Nr.: **1016 D**

Geppert-Band GmbH
Tel: 02209 / 844 90
Fax: 02208 / 843551
Bismarckstraße 141/142 51063 Köln

State Changes Date Name Filename

Page - Pg 28.11.2005

